Fig.1



Fig.2



Fig.3



Fig.4


S1
S2
SAEL
SPV
SDISP
SSELF
SCUST
SVH
SUP
SDOWN
SDATA
Micro-computer
Driver for Dot-matrix LCD
Dot-matrix LCD
Sub LCD
In Finder LCD
Shutter Control Circuit
Photometry Circuit
Auto Focus Circuit
Winder Circuit

Fig.5


CHECK
#1
S1 ?
YES
NO
#2
AUTO FOCUS
#3
CALCULATION FOR EXPOSURE
#4
S2 ?
NO
YES
#5
WINDING
C
A


A
#10
AE LOCK BUTTON ON ?
YES
NO
#11
AE LOCK
#12
SCREEN-SWITCH BUTTON ON ?
NO
YES
#20
PREVIEW BUTTON ON ?
YES
NO
#21
PREPARATION OF DATA FOR DISPLAYING A DEPTH OF FIELD
#13
PREPARATION OF DATA FOR DISPLAYING A BRIGHTNESS DISTRIBUTION
#30
SCREEN-SWITCH BUTTON ON ?
YES
NO
#31
DETAILED ?
YES
NO
#35
PREPARATION OF DATA FOR DISPLAYING AN ENLARGED FORM
#32
ENLARGED ?
YES
NO
#36
PREPARATION OF DATA FOR DISPLAYING A PHOTOMETRY INDICATION
#33
PHOTOMETRY ?
YES
NO
#37
PREPARATION OF DATA FOR DISPLAYING A PHOTOGRAPHING HISTORY
#34
PREPARATION OF DATA FOR DISPLAYING IN A DETAILED FORM
B

Fig.6


C
B
#40
SELF-TIMER BUTTON ON ?
YES
NO
#41
ENLARGED ?
YES
NO
#42
PREPARATION OF DATA FOR DETAILED DISPLAY
#43
PREPARATION OF DATA FOR ENLARGED DISPLAY
#50
VERTICAL ?
YES
NO
#51
DATA FOR DISPLAY (HORIZONTAL→VERTICAL)
#60
CALL CUSTOM-DATA-MEMORY SUBROUTINE
#80
DATA FOR DISPLAY →EXECUTION

Fig.7

Fig.8


100
A
F5.6
-0.5
AF-A
DATA
3
A
125
F5.6
-0.5
AF-A
AEL
DATA
3
AEL ON
101
Screen-switch Button ON
(1 PUSH)
110
125
F5.6
-0.5
+
2.5
3.0
2.0
2.0
2.5
3.0
-

Fig.9


100
A
F2.8
-0.5
AF-A
DATA
3
Preview Button ON
120
2000 F2.8 -0.5
ZOOM
1/4
2.9m
3.1m
9.5ft
10ft
121
122
123


100'
A
F5.6
+0.5
AF-A
23
100
Detailed Screen
Screen-switch Button
200'
200
Enlarged Screen
Screen-switch Button
300
Photometry Indicator Screen
Screen-switch Button
400
Photographing History Screen
Screen-switch Button
500
Self-timer
10S Self-timer

Fig.10


CUSTOM-DATA-MEMORY
#61
CUSTOM BUTTON ON ?
YES
NO
#62
SCREEN-SWITCH BUTTON ON ?
YES
NO
#63
LISTED-UP ?
YES
NO
#64
PREPARATION OF DATA FOR LIST-UP DISPLAY
#65
PREPARATION OF DATA FOR DETAILED DISPLAY
#71
DATA-MEMORY BUTTON ?
YES
NO
#72
SCREEN-SWITCH BUTTON ?
YES
NO
#73
LISTED-UP ?
YES
NO
#74
PREPARATION OF DATA FOR LIST-UP DISPLAY
#75
PREPARATION OF DATA FOR DETAILED DISPLAY
RETURN

Fig.11

Fig.12


CUSTOM SET-UP
A F5.6
0.0
AF-A
100
Custom Button ON
601
602
CUSTOM 1
PRIORITY
1 AF (AFP)
2 Release (RP)
front dial
CUSTOM 28
Set-up Indication
1 Yes
2 No
rear dial
CUSTOM 1
PRIORITY
1 AF (AFP)
2 Release (RP)
603
Screen-switch Button
Screen-switch Button
front dial
(change item)
CUSTOM P2/3
16-1 21-1 26-1
17-2 22-1 27-1
18-3 23-1 28-2
19-1 24-1 29-1
20-1 25-1 30-1
702
CUSTOM P1/3
1-2 6-3 11-1
2-1 7-2 12-1
3-2 8-2 13-3
4-1 9-1 14-1
5-2 10-1 15-3
701
rear dial
(change setting)
CUSTOM P1/3
1-1 6-3 11-1
2-1 7-2 12-1
3-2 8-2 13-3
4-1 9-1 14-1
5-2 10-1 15-3
703

Fig.13


DISP [dn1-0001]
No. TV AV ±
1 125 5.6 +1.5
2 250 5.6 -3.0
3 60 4 0.0
4 4000 5.6 -0.5
801
Screen-switch Button
DISP [dn1-0001]
2000. 1.12 16:35
A 125 F5.6
300MM / F2.8
±+1.5
±-0.5
1
802

Fig.14


Japanese
DISP CUSTOM 34
IDナンバー設定
【dn1-XXXX】
dn1~9が選択可能
English
DISP CUSTOM 34
ID Number
【dn1-XXXX】
dn1-9 selectable
German
DISP CUSTOM 34
ID Nummer
【dn1-XXXX】
dn1-9 wählbar
DISP CUSTOM 34
N° Identité
【dn1-XXXX】
dn1 à 9 au choix
French
DISP CUSTOM 34
Número ID
【dn1-XXXX】
dn1-9 disponible
Spanish

Fig.15


Japanese
English
German
DISP CUSTOM 35
言語選択
1 日本語
2 Eng 4 Fra
3 Deu 5 Esp
DISP CUSTOM 35
Language
1 Jpn
2 Eng 4 Fra
3 Deu 5 Esp
DISP CUSTOM 35
Sprache
1 Jpn
2 Eng 4 Fra
3 Deu 5 Esp
DISP CUSTOM 35
Langue
1 Jpn
2 Eng 4 Fra
3 Deu 5 Esp
DISP CUSTOM 35
Idioma
1 Jpn
2 Eng 4 Fra
3 Deu 5 Esp
French
Spanish

Fig.16


RESET
#90
LANGUAGE-SELECTOR ON ?
JAPANESE
ENGLISH
#91
PREPARATION OF DATA TABLE FOR ENGLISH
#93
PREPARATION OF DATA TABLE FOR JAPANESE
#92
DATA FOR DISPLAY →EXCUTION
CHECK

Fig.17